

SINGLE HAMMOCK

Step by Step Instructions



STEP 1

When you find the place to hang your hammock, you just need to take one of the nylon cords from the kit and sling it around the tree, pole, or whatever you're hanging the hammock from.



STEP 2

Holding one end of the Go Anywhere cord in each hand, just pull the knotted end through the looped end.



STEP 3

Continue pulling the knotted end towards you until the loop locks it into place on the tree. Position the rope around the tree so the cord is pulling against itself in the direction you wish to hang the hammock.



STEP 4

You may have been wondering why there are multiple knots in the Go Anywhere cord. Now, you'll understand why. Just take the s-hook at one end of the hammock and hook into the closest knot to the tree. (The pictures above are shown with our optional carabiner installed instead of the S-Hook, but the idea is exactly the same.)

Repeat the procedure for the other side, hooking into whichever pre-tied knot (or make one of your own) will give you the proper tension and distance you need to hang the hammock.

Regardless of how close or far apart the trees are you can just hook into a different knot and you'll always have the perfect hang!



PERMANENT SETUP

Because the hammock is equipped with s-hooks on either end, setting up a Trek Light Hammock on your porch, patio, indoors, or to any beam or post is a cinch. We recommend picking up eye bolts (see example image below) from any hardware store and installing them as required. Make sure you buy the appropriate size to hold the necessary weight and bolts that won't pull out of the beam or post too easily (speak with the staff at your hardware store). Just hook the s-hook or Trek Light Carabiner into the eye bolt and you're ready to go!

